

Low Emission Zone. Brussels

- To improve the air quality in the region, the Brussel-Capital Region has established a LEZ or “Low Emission Zone” since January 2018. In this zone the use of the most polluting vehicles is prohibited. The regulation affects cars, vans ≤ 3.5 tons, and buses and coaches, registered in Belgium or abroad.
- Diesel vehicles Euro 1 and 2 and vehicles without the Euro standard aren’t allowed to drive in Brussels.
- Petrol vehicles with Euro 1 standard and petrol vehicles without Euro standard are banned as well.
- However, for vehicles that don’t meet the access criteria of the LEZ it is possible to buy a day pass (35€) which will allow you to enter Brussels. This pass needs to be bought before entering the Brussels area.
- The following applies for all vehicles registered abroad: Cars (of categories M1, M2, M3 and N), both vehicles that don’t meet the access criteria as vehicles that do, must register online before their visit to Brussels using an electronic form.
- For more information, to buy a day pass or to register online, please click on the following link: <https://lez.brussels/en>